

8800R V2 External Printer Connection

Cassida 8800R V2 provides the option to display the report on the screen and print it if external printer is connected (printer not included).

Cassida 8800R V2 works best with the Cassida Thermal Printer (sold separately) and can be connected via DB9 printer cable (comes with the printer) to the machine.

Below please see instructions on how to connect external printer to the Cassida 8800R.

1. Please locate DB9 printer cable that comes with the printer.



DB9 Printer Cable

2. Connect one end of the printer cable (included with the printer) to the printer. The other end of the cable, which has a DB9 connector, must be connected to the DB9 port on the machine.





8800R V2

External Printer Connection

3. After the connection process is successfully done, make sure the Cassida 8800R V2 and the printer are both on. Count the stack of mixed denomination bills, when done, press report button on the display and then print button to print the report displayed on the screen.
4. If you have any issues with the connectivity of the printer, please contact us any time at www.CassidaUSA.com/support-contact