


NOTE: For more information regarding the configuration settings and advanced features of the TillTally, please refer to the user manual.

HOW TO **SET UP**


The TillTally must be calibrated 1) before first usage; 2) whenever it is reset to factory settings or 3) when the scale is moved or bumped. To calibrate scale, use the included 500g weight.

1



Place Cup Support Hod onto scale

2




Hod must be empty
Turn unit on by holding for 2 seconds

3




If not calibrated, **CALIBRATE SCALE** screen appears
NOTE: If already calibrated, you are ready to count when TillTally is turned on.

4




Press **OK**

5




Screen shows **ZERO**

6




500.0 g weight needed screen

7




Add weight to scale. Press **OK**

8



Screen shows **SCALE READY**

9



Remove weight. Scale turns off automatically

NOTE: By default, TillTally will automatically continue from counting coins, to counting coin rolls (if activated) to counting currency.

1¢ • 5¢ • 10¢ • 25¢

+

1¢ • 5¢ • 10¢ • 25¢
(if configured)

+


\$1 • \$5 • \$10 • \$20 • \$50 • \$100

=

Final Amount


HOW TO **COUNT COINS**

1




Press **>** to navigate to the coin counting mode

2



Fill cup with the denomination shown on the display. Place the coin cup on the scale

3




Result shows on screen. Scale automatically continues to next denomination. Repeat step 2 for other denominations. Skip a denomination by pressing the **>** key.

HOW TO **COUNT COIN ROLLS**


NOTE: By default, TillTally does not have coin rolls turned on. To turn this feature on, see **CONFIGURE FOR COIN ROLLS**

4




Press **>** to navigate to the roll counting mode

5



Place coin rolls one at a time in any denomination / order.

6




Result is shown on screen

Remove coin rolls all at once


HOW TO **COUNT CURRENCY**

7




Press **>** to navigate to the currency counting mode

8



Starting with lowest denomination, place 10-15 bills at a time. The hod can hold 200-400 bills. Once you've counted a single denomination, remove all bills at once. The next denomination will be automatically set.


9



Result is shown on screen. If you do not have denominations you need to count, use the **>** key to move to the next denomination.


HOW TO **CONFIGURE FOR COIN ROLLS**

1




To power on
CLEAR
2 seconds
Hod must be empty
Verify unit is on.

2



Press both **<** and **>** to access setup. Press **<** to select **COIN ROLL** then **OK**, **<**, **OK**

3



Exit setup by pressing **CLEAR** for 2 seconds