



CASSIDA INSTACHECK & OMNI-ID BILL LOADING GUIDE


To ensure top performance, we have listed the following steps on proper use of the Cassida InstaCheck & Omni-ID:

I. Avoid inserting a bill that is:


- Torn
- Heavily Worn
- Crumpled
- Covered with adhesive tape
- Stapled

II. Ensure the bill is flat and corners are not folded (the InstaCheck and Omni-ID can recognize the size of a bill and may reject a bill that is folded or has folded corners).

III. Insert the bill face up, exactly as shown below :



INSTACHECK



OMNI-ID

Several factors can cause the Cassida InstaCheck & Omni-ID not to recognize a genuine bill:

- Bill inserted in the wrong orientation.
- Overly wrinkled, overly creased, and overly worn bills.
- Knocking over or dropping the unit.
- A sudden change in temperature or humidity.
- Extended period of non-use.
- Lack of maintenance.

If the InstaCheck and Omni-ID consistently refuses to recognize genuine bills, turn the unit off and unplug it from the wall. Use an air duster to remove the dust from the sensors as described in the user manual. Reinsert the plug and turn the machine back on.

Because of the printing method used by the US Mint and the deterioration of most currency over time, bills are not exactly identical. This will occasionally cause a bill not to be recognized on the first run in an automatic counterfeit detector. If it recognizes a bill after the second or third attempt, you can be assured the bill is genuine.

**Thank you for purchasing with Cassida USA.
We strive to help keep your business protected
and we sincerely hope you enjoy using your
new Cassida InstaCheck or Omni-ID**