



CRS-7200 Cleaning Procedure

Dust and debris on the sensors of the CRS-7200 can lead to false readings such as DOUBLE, HALF, UV, MG, or IMAGE, diminishing the unit's efficiency

Daily cleaning is essential for optimal performance.

Preparation:

Disconnect the unit from power before any cleaning activity.

Cleaning Agents:

Use only mild cleaning solutions. Harsh chemicals, including thinner and alcohol, must be avoided to prevent damage.

Routine Cleaning:



Utilize the dry cloth and brush provided by the manufacturer for the sensors and rubber rollers, ensuring accurate operation and smooth functionality. For an in-depth clean, manufacturer recommends swabs and cards, which are available for purchase online or through Cassida Technical support. If these are not available, a can of compressed air and a soft brush can effectively remove internal dust.

Dust Protection:

Use the included dust cover to protect the unit when not in operation, especially over extended periods, to prevent dust accumulation.

Following these steps ensures the CRS-7200 remains in excellent condition, extending its operational lifespan and maintaining high performance.


Step 1: Open Top Cover.






CRS-7200 Cleaning Procedure



Step 2: Lift the top part of sensor block to access sensors.



Step 3: Locate the bottom IR sensor bar. Bar with a glass finish.




Step 4(a): Clean bottom IR bars with a fiber cloth or brush. Fiber cloth or brush comes with a unit.



CRS-7200 Cleaning Procedure

Step 4(b): Clean adjacent top IR sensor with a fiber cloth. Sensor is located at the bottom of sensor block's top part. Fiber cloth comes with a unit.




CRS-7200 Sensors:

1. Hopper - One sensor pair
2. Stacker - One sensor pair
3. Infrared Line (IR) - Two sensor bars
4. Ultraviolet (UV) - One sensor pair
5. Magnetic (MG) - One sensor pair

Clean all the sensors that are shown in pictures with fiber cloth & brush.

CRS-7200 Cleaning Procedure



If, after cleaning all sensors, this does not resolve the issue, please see the support section on Cassida USA website at www.Cassidausa.com, or contact Cassida Support at support@Cassidausa.com for further troubleshooting.